




ISOLOG 3D

QUICKGUIDE | NETWORK




- 1 Right mouse button on the *network symbol* in the task bar
- 2 Click "*Open Network and Sharing Center*"
- 3 Click "*Local Area Connection*"




ISOLOG 3D

QUICKGUIDE | NETWORK




4



5

6

- 4 In the menu, click „*Properties*“
- 5 Select “*Internet Protocol Version 4 (TCP/IPv4)*”
- 6 Click “*Properties*”



7 Fill the form fields as shown

IsoLOG Static IP-Address:
192.168.100.115

